



## SPEED CALLING

Now you can reach those you call frequently, whether locally or long-distance, by dialing only one or two digits. With SPEED CALLING, you program your phone to dial a complete number in response to a one or two-digit code dialed by you. It's especially useful for emergency assistance numbers, when time is critical.

You can select either a short list of eight telephone numbers (**SPEED CALLING 8**) or a long list of 30 telephone numbers (**SPEED CALLING 30**). If you have opted for SPEED CALLING 8, but want to be able to speed dial more numbers, just call and let us know. We can easily change your service to SPEED CALLING 30.

### To program or change your SPEED CALLING 8 list...

- Lift the handset and listen for the dial tone.
- Dial \*74. (On a rotary dial phone, dial 1174 and wait four seconds.)
- Listen for the dial tone.
- Dial one of the eight one-digit speed codes (2 through 9).
- Then, dial the number you wish to speed call. (For long distance entries, remember to include 1 and the area code.)
- Press the # button. (On a rotary dial phone, omit this step and wait four seconds.)
- Listen for the two "beeps" which indicate that your number has been entered. Then hang up.

You can now continue entering the other numbers on your list by repeating the above procedure, or you can enter them later.

### To use your SPEED CALLING 8 feature...

- Lift the handset and listen for the dial tone.
- Dial the appropriate one-digit speed code (2 through 9).
- Press the # button. (On a rotary dial phone, omit this step and wait four seconds.)
- Your call will now be dialed automatically.

### **To program or change your SPEED CALLING 30 list...**

- Lift the handset and listen for the dial tone.
- Dial 75. (On a rotary dial phone, dial 1175 and wait four seconds.)
- Listen for the dial tone.
- Dial one of the 30 two-digit speed codes (20 through 49).
- Then, dial the number you wish to speed call. (For long distance entries, remember to enter 1 and the area code.)
- Press the # button. (On rotary dial phones, omit this step and wait four seconds.)
- Listen for the two "beeps" which indicate that your number has been entered. Then hang up.

You can now continue entering the other numbers on your list by repeating the above procedure, or you can enter them later.

### **To use your SPEED CALLING 30 feature...**

- Lift the handset and listen for the dial tone.
- Dial the appropriate two-digit speed code (20 through 49).
- Press the # button. (On rotary phones, omit this step and wait four seconds.)
- Your call will now be dialed automatically.

**To order this service or for more information, contact NATCO Customer Service at 1-800-775-6682.**